User Manual

Notes and Notices

📖 Notes

A NOTE indicates important information that helps you make better use of your mobile phone.

Notices

A NOTICE indicates either potential damage to the phone or loss of data and tells you how to avoid the problem.

Friendly Tips

Thank you for choosing this phone. If description, photographs and actual products are nuances please refer to products. For mobile phone version upgrade, further notice please contact with the customer service.

Our company will reserve the right of modifying the contents of manual under any circumstance without need notify in advance.

Contents

1 Your Phone 6
1.1 Basic Specification 6
1.2 Keys Definition 6
1.3 Screen Icons 8
2 Getting Started 9
2.1 Install/Remove Battery 9
2.2 Battery Charging 11
2.3 Install/Remove R-UIM Card 12
2.4 Headset 13
2.5 Memory Card 13
3 Basic Function 14
3.1 Power on/Power off 14
3.2 Making a Call 14
3.2.1 Input a Number 14
3.2.2 Call a number from Records 14
3.2.3 Speed Dialing 14
3.2.4 Conference Call 15
3.3 Answer a Call 15
3.4 During Conversation 15
4 Text Input 16
4.1 Input Rule 16
4.2 Text Input 16
4.3 123 Input 16
5 Main Menu 16
5.1 Contacts 16
5.1.1 Speed Dialing 17
5.1.2 Memory Status 17

5.1.3 My Number 17
5.2 Messages 17
5.2.1 Messages 17
5.2.2 MMS 20
5.3 Call History 21
5.3.1 Missed Calls 21
5.3.2 Received Calls 22
5.3.4 Dialed Calls 22
5.3.5 Call Duration 23
5.3.6 Delete 23
5.4 Tools 23
5.4.1 Bluetooth 23
5.4.2 Alarm 23
5.4.3 Calendar 23
5.4.4 Memo 24
5.4.5 Calculator 24
5.4.6 Auto Power Off 25
5.4.7 World Clock 25
5.4.8 Stopwatch 25
5.4.9 Timer 25
5.4.10 Currency Converter 25
5.5 Multimedia 26
5.5.1 Camera 26
5.5.2 Music Player 26
5.5.3 Image Viewer 26
5.5.4 FM Radio 26
5.5.5 Video Recorder 27
5.5.6 Video Player 27

5.5.7 Sound Recorder 28
5.6 My MTS 28
5.6.1 MTS Planet 28
5.6.2 Games & Application 28
5.8 Games 29
5.8.1 Push box 29
5.8.2Tetris 29
5.9 File Manager 30
5.10 MTS info 30
5.11 Browser 30
5.12 Settings 31
5.12.1 User Profiles 31
5.12.2 Phone Settings 32
5.12.3 Call Settings 32
5.12.4 Display settings 33
5.12.5 Security settings 33
6 Important Safety Precautions & Notices 35
7 Frequently Asked Questions and Troubleshooting 36

1 Your Phone

1.1 Basic Specification

1.2 Keys Definition

Key No.	Key Image	Key Name	Description
1		Left Soft key	Execute the displayed function on the left bottom line. Enter main menu in standby mode.
2		Right Soft key	Execute the displayed function on the right bottom line. In the pop-up submenu interface, press it to close the submenu. In the editing interface, press it to

Key No.	Key Image	Key Name	Description
			delete the latest character press and hold it to delete all the characters. In the others, press it to exit.
3		Send key	From the idle screen press it to enter the [Dialed calls]. Dial or answer a call.
4		End key	Reject an incoming call. Go back to standby screen Press it to exit. Press and hold it to power on/off handset.
5		Browse key	From the idle screen, press it to open Browse.
6		Facebook key	From the idle screen, press it to enter Facebook application interface.
7		Navigation key	Down: Press it to enter Write Messages interface, Right: Press it to enter FM Radio interface , Up: Press it to enter User Profiles interface, Left: Press it to enter Games interface. In the others, press the navigation key to move the cursor.
8		OK key	Execute the confirm function.
9		QWERTY	Enter numbers, letters and symbols

Key No.	Key Image	Key Name	Description
		keys	using the qwerty keypad.
10		Receiver	Listen to the voice of the other side during calling.
11		Earphone Jack	Insert earphone to listen songs from Music Player, listen FM and answer call using earphones.
12		USB Jack	Connect USB cable for data transfer and for charging the handset.
13		Camera	1.3 MP Camera to take photos and capture videos.
14		Speaker	Can play songs, listen FM and can talk on Loudspeaker mode.

📖 Note

(1) Press and hold a key means press the key more than 2 seconds. Press a key means press it less than 2 seconds,

(2) In the menu interface, press the number before the menus to enter the cursor quickly.

1.3 Screen Icons

Icons	Description
	Signal Indicator, More bars indicates stronger signal

	New Message Icon
	Full Messages Icon
	New MMS
	Full MMS Icon
	Roaming Icon
	General Mode
	Meeting Mode
	Outdoor Mode
	Silent Mode
	FM Radio Icon
	Alarm Icon
	Call Firewall Icon
	Message Firewall Icon
	Call Firewall and Message Firewall
	Keypad Lock Icon
	Phone Locked Icon
	Memory Card
	Battery Level Indicator

2 Getting Started

2.1 Install/Remove Battery

Use lithium-ion battery, please use the original manufacturers or

authorized batteries and take care of the battery.

Cover: Slip the cover downwards to remove the cover. Press the cover upwards to install it.

Battery: Put battery into the back of the phone press the underside till locked. Put the battery up, and then remove it.

⚠ Notice

Press and hold End key to power off. Remove the battery after wait about 10 seconds avoid to damage the storage.

2.2 Battery Charging

Before Charging you must confirm the phone adapter is original provided by the manufacturer or unauthorized.

⚠ Notice:

（1）Please use the charger provided by the original manufacturer.

（2）Do not charge the mobile phone without battery in order to avoid damaging the phone or adapter.

（3）Do not insert charging cable forcefully to avoid damage to the phone or adapter.

（4）For the first few times, please charge the battery fully.

（5）The battery will be automatically discharged, please charge it when it is not used for a long time.

（6）When not in use, please separate the battery from power supply. Overcharging shorten the life of the battery.

（7）Do not expose your products to extreme high or low temperatures.

2.3 Install/Remove R-UIM Card

Before you use the phone, please insert an effective card.

Install R-UIM card: Slip the card. Make sure that the gold-colored contacts on the card face down into the phone and notice the angles cutting.

Remove R-UIM card: Slip the card on the contrary to remove it.

⚠ Notice

（1）Must power off the phone and disconnect charger and then continue to remove the R-UIM card.

（2）Please do not touch the metal area to avoid losing and breaking the information in the R-UIM card. Put the R-UIM card far from electricity and magnetism.

（3）R-UIM card must be in the place with the temperature -20℃ to 85℃..

（4）Please put the R-UIM card out of the reach of the children.

2.4 Headset

This phone has a headset. Before using it, please plug in on the left side. After you insert the headset you can use it to listen to FM radio. When you have an incoming call press and hold the button of the headset to answer/reject the call.

2.5 Memory Card

Memory Card is an extended memory card that stores multimedia files.

Install the Memory card: Slip the cover according to the “Open⇦” arrow to open the cover and then put in the card. Slip the cover according to the “Close⇨” arrow to lock the cover. Remove the Memory card: Slip the cover contrarily.

3 Basic Function

3.1 Power on/Power off

Press and hold End key to power on device when it has enough Battery. If you have enabled the Phone lock or R-UIM lock, please input the Password or PIN code when power on. The detail is in [Menu/Settings/Security settings/Phone lock] and [Menu/Settings/Security settings/ R-UIM lock].

When the keypad was locked please press Left Soft key and * to unlock it and then power off. When the phone was unlocked you can press and hold End key to power off directly.

3.2 Making a Call

3.2.1 Input a Number

From the idle screen press Number key to input the telephone numbers and then press Send key to make a call or press Left Soft key to display the submenu: Call, Save number, Send message and Edit.

Call: Call the entered number.

Save number: Save the entered number to the phone book.

Send message: Edit and send a message to the entered number.

Edit: Edit the numbers.

3.2.2 Call a number from Records

From the idle screen press send key to enter Dialed call interface. In the list interface you can choose someone and press Send key to dial it. The detail operation is in [Menu/Call History/Dialed calls].

3.2.3 Speed Dialing

From the idle screen you can press and hold 1-9 keys to speed dial numbers. If you cannot set it when you press it the phone will prompt “No speed dial set?” Press Left Soft key to set it now. The detail is in [Menu/contact/Speed dialing].

3.2.4 Conference Call

During the conversation input the third number from the phonebook or input the numbers by the keypad directly. And then create the conference call by accessing options, press Send key to begin it after the third one answer the call.

📖 Notes

（1）If the contact has several numbers you can set someone as default and so when you dial the contact it will dial the set number. If you did not set someone as default you will call the contact of the first number.

（2）Before you use the Conference Call please confirm that the local network support this function and the R-UIM card opened this function too.

3.3 Answer a Call

When you have an incoming call your phone rings or vibrates depending on the parameters you choose. However if the number has been stored in the phonebook, the caller's name will be displayed.

You can press Send key to answer it or you can answer it by other ways that you can set the answer mode in [Menu/Settings/Call settings/Answer mode] otherwise you can press End key to reject it.

3.4 During Conversation

During the active call press Left Soft key to display the submenu: H-Free /H-Held, Mute/Unmute, Contacts and Messages.

H-Free/H-Held: You can open or cancel the hand-free function.

Mute/Unmute: After you set Mute the partner cannot listen your voice. And then select Unmute to reset it.

Contacts: Enter the Phonebook and view the contacts.

Messages: Enter the message interface to execute some operations.

.

4 Text Input

4.1 Input Rule

(1) In the text input interface press Input key to switch the methods.
(2) a/A Key: Press this key to switch case sensitive.
(3) Alt Key: Hold this key and then press the other keys to input the symbols.
(4)Sym Key: To insert characters which are not shown on the keypad.

4.2 Text Input

In Text input interface you can press QWERTY keys to input letters.
For example: “happy”
You can press “h, a, p, p, y” to input it.

4.3 123 Input

In 123 input, press 0~9 to input numbers, press “Input” key to switch the input type.

5 Main Menu

5.1 Contacts

From the idle screen select [Menu/contacts] to display the submenu: Add new contact, Search, Caller groups, Copy all, Move all, Delete, Speed dialing, Memory status and My number.

From the idle screen press Right Soft key to display the contacts list. Press Left/Right key to switch the group. Press OK key to view the current contact, press Left Soft key to display the submenu: Call, Edit, Send Message, Delete, Copy to R-UIM/Phone, Move to R-UIM/Phone and Add to Blacklist.

Call: Dial the current number.

Edit: In the detail interface press Left Soft key to edit interface. After editing the contents you can press OK key to save. Meanwhile when you edit the numbers you can select Edit and Save as default. You can set someone as default and so when you dial the contact it will dial the set number. If you

did not set someone as default you will call the contact of the first number.
Send message: Edit and send a message to the current number.
Delete: Delete the current contact.
Copy to R-UIM/Phone: Copy the current contact from R-UIM card to Phone or copy it from Phone to R-UIM card.
Move to R-UIM/Phone: Move the current contact from R-UIM card to Phone or move it from Phone to R-UIM card.
Add to Blacklist: Add the current contact into the blacklist. Once any contact is added to blacklist then someone and press OK key to delete.

5.1.1 Speed Dialing

From the idle screen select [Menu/ Contacts/Speed dialing] to edit numbers of 1-9. If the key does not set press Left Soft key/OK key to add numbers from Phonebook otherwise press Left Soft key to display the submenu: View, Edit, Assign and Remove.
View: View the set numbers.
Edit: Edit the set numbers.
Assign: Enter the phonebook and select a number again.
Remove: Erase the set numbers.

5.1.2 Memory Status

From the idle screen select [Menu/ Contacts/Memory status] to view the capacity of R-UIM and Phone.

5.1.3 My Number

From the idle screen select [Menu/ Contacts/my number] to View, Edit and Save your R-UIM number.

5.2 Messages

5.2.1 Messages

Write Message

From the idle screen select [Menu/Messages/Messages/Write Message] to the edit interface, please refer to “text input” in edit operation.

In the edit interface press Left Soft key to display the submenu: Insert Symbol, Insert Smiley, Insert Templates, Insert Contact and Save to Drafts.
Insert Symbol: Select a symbol and insert it in the edited message.
Insert Smiley: Select a smiley and insert it in the edited message.
Insert Templates: Select a text and insert it in the edited message.
Insert Contact: Select information of the contact and insert it in the edited message, except for group, remark and Ringtone.
Save to drafts: Save the edited message to the drafts. After editing press OK key to enter the address list. In the address list input numbers from the keypad or select numbers from the Phonebook/Call logs. After editing numbers press Left Soft key to display the submenu: Send & Save, Send Only, Enter from Phonebook and Enter from Call History.
Send & Save: Send the edited message and save it in Sent Items too.
Send Only: Send the edited message but do not save it.
Contacts: Select number from the Phonebook to add into the address.
Inbox

From the idle screen select [Menu/Messages/Messages/Inbox] to display the list interface. Press OK key to view the content of the current message. Press Left Soft key to display the submenu: Delete and Multiple Delete.
Delete: Delete the current message.
Multiple Delete: You can select some messages to delete. In the content interface, press OK key to reply it. Press Left Soft key to display the submenu: Call Back, Forward, Delete, Save Number and Copy to R-UIM/Phone.
Call Back: Call the number of the sender.
Forward: Edit the message again and then send to others.
Delete: Delete the current message.
Use Number: Take the number out of the message and save them in the

Phonebook.

URL Retrieve : Using this option user can retrieve a URL link present in the message content.

Copy to R-UIM/Phone: Copy a message from one type of memory to another.

Drafts

From the idle screen select [Menu/Messages/ Messages/Drafts] to display the list interface. Press OK key to view the content. Press Left Soft key to display the submenu: Forward, Delete, and Multiple Delete.

Forward: Edit the message again and then send the others.

Delete: Delete the current message.

Multiple Delete: You can select someone to delete. In the content interface, press Left Soft key to edit it again.

Outbox

From the idle screen select [Menu/Messages/Messages/Outbox] to display the list interface. Press OK key to view the content. Press Left Soft key to display the submenu: Resend, Delete and Multiple Delete.

Resend: Resend the sent message.

Delete: Delete the current message.

Multiple Delete: You can select to delete some messages together. In the content interface press OK key to enter the edit interface. Press Left Soft key to display the submenu: Forward, Delete, and Copy to R-UIM/Phone.

Forward: Edit the message again and then send the others.

Delete: Delete the current message.

Copy To R-UIM/Phone: Copy the current message from Phone to R-UIM or from R-UIM to Phone.

SMS Settings

From the idle screen, select [Menu/Messages/Messages/SMS Setting] to display the submenus: Priority Set, Storage Location, Delivery Report,

Save Sent Message, Memory Status and SMS on Call Reject.

Priority Set: you can select message priority as normal or urgent.

Storage Location: You can select Phone or R-UIM memory. If you select Phone Memory then the received message will save in R-UIM automatically when the phone memory is full and then the new received SMS will be saved on R-UIM card.

Save Sent Message: Set that whether you need to save the sent message.

Memory Status: View the memory status of phone and R-UIM.

Delivery Report: You can set delivery report Open/Close.

SMS on Call Reject: You can set it as On/off and Edit Message texts that will be sended when a Call is rejected using "SMS on Call Reject.

Delete All SMS

From the idle screen select [Menu/Messages/ Messages/Delete all] to display the submenu: Inbox, Drafts, Sent Items, and All Messages.

Inbox: Delete the entire messages in Inbox.

Drafts: Delete the entire messages in Drafts.

Sent Items: Delete the entire messages in sent items.

All Messages: Delete all the messages in all the Messages folder.

5.2.2 MMS

Multimedia Message Service (MMS) delivers messages containing a combination of text, Images, Videos and Sound from phone to phone.

New MMS

From the idle screen, select [Menu/ Messages/MMS/New MMS] to edit a new MMS.

Inbox

From the idle screen select [Menu/ Messages/MMS/Inbox] to display the list. Select any Message and press Left Soft key to execute operations about it.

Outbox

From the idle screen select [Menu/ Messages/MMS/Outbox] to display the list. Select any message and press Left Soft key to execute operations about it.

Drafts

From the idle screen select [Menu/ Messages/MMS/Drafts] to display the list. Select any message and press Left Soft key to execute operations about it.

Sent

From the idle screen select [Menu/ Messages/MMS/Sent] to display the list. Select any message and press Left Soft key to execute operations about it.

Templates

From the idle screen select [Menu/ Messages/MMS/Templates] to display the list.

Settings

From the idle screen select [Menu/ Messages/MMS/Settings] to set Profile, Send, Receive, Edit, View Mode and Memory Status.

Profile: Select MMS settings to edit and activate it.

Send: Set the options that Delivery Report, Save Sent Items, Validity Period and Delivery Time.

Receive: Set the options that Send Delivery Report and Retrieval Mode.

Edit: Edit Signature and Slide Timing.

View Mode: Choose Auto or Manual.

Memory status: View the Space Used, Free Space and Usage rates.

5.3 Call History

5.3.1 Missed Calls

From the idle screen select [Menu/Call History/Missed Calls] to display the missed calls list. Press OK key to view the detail. Press Left Soft

key to display the submenu: Save, Add to Black List, Send Message and Delete.

Save: Save the number of the missed call in Phonebook.

Add to BlackList: Add the number of the missed call in the Black List.

Send Message: Send a message to the number of the missed call.

Send MMS: Send a message to the number of the missed call

Delete: Delete the current missed call.

5.3.2 Received Calls

From the idle screen select [Menu/Call History/Received calls] to display the incoming calls list. Press OK key to view the detail. Press Left Soft key to display the submenu: Save, Add to Black List, Send Message , Send MMS and Delete.

Save: Save the number of the missed call in Phonebook.

Add to BlackList: Add the number of the missed call in the Black List.

Send Message: Send a message to the number of the missed call.

Send MMS: Send a message to the number of the missed call

Delete: Delete the current missed call

5.3.4 Dialed Calls

From the idle screen, select [Menu/ Call History/Dialed calls] to display the Dialed calls list. Press Left Soft key to display the submenus: Save, Add to Black List, Send Message and Delete.

In the detail interface, press OK key to call the current number, press Left Soft key to display the submenus: Save, Add to Black List, Send Message, Send MMS and Delete.

Save: Save the number of the missed call in Phonebook.

Add to BlackList: Add the number of the missed call in the Black List.

Send Message: Send a message to the number of the missed call.

Send MMS: Send a message to the number of the missed call

Delete: Delete the current missed call

5.3.5 Call Duration

From the idle screen select [Menu/Call History/Call Duration] to display the submenu: Last Call, Total Received, Total Dialed and Total Call. In the time interface press Left Soft key to clear the time.

5.3.6 Delete

From the idle screen select [Menu/Call History/Delete] to display the submenu: Missed Calls, Received Calls, Dialed Calls and Delete All.

5.4 Tools

5.4.1 Bluetooth

From the idle screen select [Menu/Tools/Bluetooth] to display the submenu: Bluetooth On, Device Search, Devices, My Info and Settings.

Set the Bluetooth status as ON first and then select All Devices in the menu of Device Search. When finished searching select one device to bond. After bonded you can transfer file with each other by Bluetooth.

5.4.2 Alarm

From the idle screen select [Menu/ Tools/Alarm] to edit three alarm clocks. Select any and press Left Soft key to turn alarm on/off. Press OK key to enter the edit interface. Edit the time from the keypad, press Up/Down key to select options and press Left/Right key to select the content of the options. After set completed press Left Soft key to confirm.

If the phone is in the Power Off mode the alarm will prompt you. Press Left Soft key to Power On and press Right Soft key/End key to exit or after the prompt it will still be in the Power Off mode.

5.4.3 Calendar

From the idle screen select [Menu/ Tools/Calendar] to display the schedule interface. Press OK key to View the current event and press Left Soft key to display the submenu: Jump to Date, Add New Event, View All, Delete and Delete All Events.

Jump to Date: Using this you can see the set events from 1-1-1980 to 31-

12-2059.

Add New Event: Enter the edit interface to input events.

View All: View all the events in the list. In the list interface press OK key to view the content of the current event and press Left Soft key to display the submenu include Edit, New plan, Delete and Delete all.

Delete: Delete the current event.

Delete all Events: Delete all the events in the list.

5.4.4 Memo

From the idle screen select [Menu/Tools/Memo] to display the memo list. If it has no record press Left Soft key to enter the edit interface, if it has several records press Left Soft key to display the submenus: View, Edit, New , Delete and Delete all.

View: View the content of the record.

Edit: Edit the record and press Left Soft key to save it. Please refer to "Text Input".

New: Add a new memo.

Delete: Delete the current record.

Delete all: Delete all the records in the memo.

5.4.5 Calculator

From the idle screen, select [Menu/Tools/Calculator] to display the calculator interface.

Keys	Functions
Number key	Input 0~9 numbers
Up/Down/Left/Right key	Up: "×" Down: "÷" Left: "+" Right: "—"
*	"."
#	"±"

Keys	Functions
Right Soft key	Exit
OK key	“═”

5.4.6 Auto Power Off

From the idle screen select [Menu/Tools/Auto Power off] to input the time of power off. You can press Up/Down key to select options, press Left/Right key to select the content of the options. After set completed press OK key to confirm.

5.4.7 World Clock

From the idle screen select [Menu/ Tools/World clock], press Up/Down/Left /Right key to switch the cities to view the time of them.

5.4.8 Stopwatch

From the idle screen select [Menu/ Tools/Stopwatch]. Press Left Soft key to start it. During timing press Left Soft key to save the Lap timing. You can save 15 records at a time. Press Right Soft key to stop it. In the stopping interface, press Left Soft key to Reset Stopwatch and press Right Soft key to exit.

5.4.9 Timer

From the idle screen select [Menu/Tools/Timer]. Press Left Soft key to set the timer, press Left/Right key to input the time “00: 00: 00”（HH: MM: SS）. The biggest value is “23: 59: 59”（23h:59m:59s）. Press OK key to open/stop it. The phone will prompt you on time.

5.4.10 Currency Converter

From the idle screen select [Menu/Tools/Currency Converter] press Left/Right key to select the type of Currency. When the cursor move to the rate input the value and press OK key to save it. After that input the numbers and press OK key to get a result.

5.5 Multimedia

5.5.1 Camera

From the idle screen select [Menu/Multimedia/Camera] to display the camera interface. Top-Right menu: Resolution, Self-timer, White Balance, Effect Settings, Settings.

Resolution: 144*176, 240*320,480*640,960*1280.

Self-Timer: 0s, 2s, 5s,10s.

White Balance: Daylight Mode, Auto White Balance, Night Mode

Effects Settings: Choose Photo style setting.

Settings: Using this you can choose the location where you want to save to Camera Photos.

5.5.2 Music Player

From the idle screen, select [Menu/Multimedia/Music player] to display the playing interface. Execute the operations as follows:

Keys	Function
OK key	Play/Pause
Up key	Volume increase
Down key	Volume decrease
Left key	Play previous song
Right key	Play next song
LSK	To access option
RSK	Exit

5.5.3 Image Viewer

From the idle screen select [Menu/Multimedia/Image Viewer] to display the Image viewer interface. Select **Image Viewer** to open the File Manager to look the photos.

5.5.4 FM Radio

From the idle screen select [Menu/Multimedia/FM Radio] to enter

the radio interface. Press Left/Right key to adjust the radio frequency, Press Up/Down key to adjust the volume. Press OK key to open or close the radio. Press Right Soft key to background playing, press End key to end it.

Under the open status, press Left Soft key to display the submenu: Save, Channel List, Loudspeaker, Manual Input, Auto Search & Save.

Save: Save the current channel.

Channel List: Show the saved channel list. You can choose a channel to play or delete it.

Loudspeaker: Play the FM Radio on the loudspeaker mode.

Manual Input: Input one channel manual and play it.

Auto Search & Save: Search the channel automatically and save it to the channel list.

5.5.5 Video Recorder

From the idle screen select [Menu/Multimedia/Video Recorder] to display the recorder interface. Top-Right menu: Size, Self-timer, White Balance, Effect Settings, Settings.

Size: 96*128, 144*176.

Self-timer: 0s, 2s, 5s, 10s.

White balance: Daylight Mode, Auto White Balance, Night Mode

Effects settings: Choose the Video background effect settings.

Settings: Using this the user can choose the location where he wants to save the recorded files.

5.5.6 Video Player

From the idle screen select [Menu/Multimedia/Video Player] to display the playing interface. Then open the video file present in Phone Memory Video or My Data folder or Memory card. You should put videos file in this folder first.

Execute the operations as follows:

Keys	Function

LSK/OK key	Play/Pause
RSK key	Stop
Up/Down key	Volume Adjust

5.5.7 Sound Recorder

From the idle screen select [Menu/Multimedia/Sound Recorder] to display the recorder interface.

Under the open status press Left Soft key to display the submenu: Voice folder, Recorder location.

Voice Folder: Enter the Recorded sounds file list.

Recorder Location: Select recorder location to select the memory where you want to save recorded files.

5.6 My MTS

5.6.1 MTS Planet

From the idle screen, select [Menu/ My MTS / MTS Planet]. Connect to pre-set website of MTS Planet.

5.6.2 Games & Application

From the idle screen, select [Menu/ My MTS / Games & Application]. Connect to pre-set website of Games & Application.

5.7 Facebook

How to access FB

For Existing users –

Go to menu>Select My MTS> Select facebook application>Enter your login id and password> Access your account successfully.

For First time login:

Go to menu>Select the My MTS> Select facebook application >Select sign up> Fill all query's> Back> Enter your login ID and password > Access your

account successfully.

5.8 Games

5.8.1 Push box

From the idle screen select [Menu/Games/Pushbox]. The aim is to put all the boxes to the appointed place, once you put all the boxes to appointed places than that level is cleared and you can go to the next one.

New game: Start a new game.

Select stage: Input a number of stage which between is between 0 and 99.

Game help: View the key definition for help.

Keys	Function
1	Select stage backwards
3	Select stage upwards
2/Up key	Up
4/Left key	Left
6/Right key	Right
8/Down key	Down
#	Open/Close the sound
Left Soft key	Restart the game
Right Soft key	Exit

5.8.2Tetris

From the idle screen select [Menu/Games/Tetris]. The aim is to adjust the direction and place of diamonds when it drops down and try to align them in a line on the bottom.

New game: Start a new game.

Game level: Select the levels of the game.

High Score: View the former six scores.

Key help: View the key definition for help.

Keys	Function

2/Up key	Turn round
4/Left key	Left
6/Right key	Right
8/Down key	Down
Left Soft key	Replay
Right Soft key	Exit

5.9 File Manager

Manage the files saved in Phone Memory and Memory Card.

5.10 MTS info

From the idle screen select [Menu/MTS info] to enter the MTS info. The content of submenus depends on the R-UIM card.

5.11 Browser

The Wireless Application Protocol (WAP) on your phone allows you to access the wireless web. From the wireless web you can access updated information and a wide variety of media content, such as wallpapers, ringtones, and music files.

Enter URL: Enter a URL address manually.

Homepage: Connect your phone to the network and load the homepage of the wireless web service provider.

History: Show all history records that you have visited.

Bookmarks: Save URL addresses to quickly access a website.

Detail: Show the detail of web address.

Update Page: Refresh the web address.

Save Page: Save web address.

Save Content: Save contents of web.

Main menu: Menu list.

Main menu→Advanced Options→Proxy: You can set the WAP parameters in Proxy server manually.

Exit: close browser.

5.12 Settings

5.12.1 User Profiles

General

From the idle screen select [Menu/Settings/User Profiles/General] to display the submenu: Activate and Customize. If you do not set the profiles again please select activate the General mode otherwise you can set Ring Settings, Volume Settings and Alert Type Settings.

Ring Settings: Set Ringtone, Message Tone, Alarm Tone, Power On/Off Tone.

Volume Settings: Press Up/Dow/Left/Right key to adjust Ringtone, Voice Volume and Key Tone Volume.

Alert Type Settings: It includes Alert Setting, Message Alert and Missed Call Alert.

Meeting

From the idle screen select [Menu/Settings /User Profiles/Meeting] to display the submenu: Activate and Customize. The detail operation is as same as [Menu/settings/User Profiles/General].

Outdoor

From the idle screen select [Menu/Settings /User Profiles/Outdoor] to display the submenu: Activate and Customize. The detail operation is as same as [Menu/settings/User Profiles/General].

Silent

From the idle screen select [Menu/Settings/User Profiles/Silent] to display the submenu: Activate and Customize. The detail operation is as same as [Menu/settings/User Profiles/General].

Flight Mode

When you set flight mode status as “On” then all the network related functions become inactive.

5.12.2 Phone Settings

From the idle screen select [Menu/Settings/Phone Settings] to display the submenu: Language, Auto Power OFF, Time Format, Date Format, Auto Keypad Lock, Memory Card Format, USB function, Version info.

Language: Select the language of display of Menu functions.

Time Format: Select display time format as 12 hours or 24 hours.

Date Format: Select date time format as DD-MM-YYYY, MM-DD-YYYY or YYYY-MM-DD

Auto Keypad Lock: Set the auto keypad lock time. It includes none, 15 sec., 30 sec. or 60 sec. If you turn on this function, the keypad will be locked on time without any operations. You can press left soft key and * key to unlock phone.

Memory Card format: Format all your memory card data using this function.

USB Function: You can connect your handset with PC when select status as "Open" .By setting the status as "Open" you can transfer data from your computer to your memory card or vice versa.

Version info: View the phone information like Software version , Hardware Version, MEID, PRL details.

5.12.3 Call Settings

From the idle screen select [Menu/Settings/Call Settings] to display the submenu: Answer Mode, Time Reminder, Call Waiting, Call Forward and International Call.

Answer Mode: Select Any Key Answer or Send Key. If you choose Any Key Answer you can press any keys to answer the incoming call except for Right Soft key and End key.

Time Reminder: Set the time of the minute reminder during conversation.

Call Waiting: After you open this function the network terminal will give a

prompt when you have an incoming call when your phone is busy. You can press Send key to switch the two conversations.

Call Forward: If you register the function you can forward the incoming call to another phone. Press OK key to view the submenu as follows: “All” means that you can forward all the incoming calls to the specific number. “Busy” means that you can forward the incoming call to the specific number when you are busy. “No Answer” means that you will forward the incoming call to the specific number when the phone has no answer. Default means that you will forward the incoming call to the specific number when your phone is off or has no signal.

International Call: Set international calls: Automatic or Manual.

📖 Note

Call forward needs the network support and your R-UIM card opened this function.

5.12.4 Display settings

From the idle screen select [Menu/Settings/Display Settings] to display the submenu: Wallpaper, Menu Style, Backlight, Brightness, Banner and Themes.

Wallpaper: Set wallpapers present in default option or you can also choose wallpapers present in your memory card.

Menu Style: Set Matrix or List as the Menu Style.

Backlight: You can select 10 sec., 20 sec., 30 sec. 60 sec. or Always on.

Brightness: Press Up/Down key to adjust the brightness.

Banner: Edit and display the banner.

5.12.5 Security settings

From the idle screen select [Menu/Settings/Security Settings] input the phone default PSWD (Password: 0000) to display the submenu: Phone Lock, R-UIM Lock, Data Protection, Call Firewall, Message Firewall, Storage

Erase, Reset Factory Settings and MTS Mobile Tracker.

Phone Lock: Activate, Change Password or Deactivate Phone Lock. Before you change the password please activate it firstly. If you activate phone lock and reboot the phone once then next time you have to enter this password to access menu functions.

R-UIM lock: If you activate R-UIM lock and reboot the phone once then next time you have to enter this password to access R-UIM card functions.

MTS Mobile Tracker: Edit five numbers and set them as the third-party numbers to receive the tracker messages. You can press * key to delete numbers. Now whenever a new R-UIM card is inserted in your MTS phone you will receive the following message from the New R-UIM card number – *Dear MTS Mobile Customer : Your mobile is used by this sender with MEID XXXXXXXX in case your mobile phone is lost or Stolen*.

Data Protection: If you open this function you can select the data protection option for the following items Contacts, Messages and Call History. So that only you can access these items after inserting the set password.

Call Firewall: It includes Incoming Restrict and Restrict All Calls. Select Incoming Restrict to restrict all incoming calls or "Blacklist" to block call only from the numbers added in the list.

Message Firewall: It includes Incoming Restrict and Restrict All Messages. Select Incoming Restrict, to restrict all incoming messages or select "Blacklist" to block messages only from the numbers added in this list.

Storage Erase: Erase the user information in R-UIM card and Phone.

Reset factory settings: Reset the phone and the parameters will be reset to the ones which were there when the phone was out of the factory.

⚠ Notice

（1）When you input a wrong PIN code thrice, the R-UIM card will be locked.

（2）If the R-UIM card was locked you can only use the PUK code to unlock it. Please contact with the network provider to receive the PUK code.

（3）If you input the wrong PUK code ten times the R-UIM card will be disabled. Please contact with the network provider to provide you a new card.

6 Important Safety Precautions & Notices

Before using the phone please read the safety precautions carefully and let your children know these so that you can use your phone correctly and safely.

Your mobile phone model has been designed to compile with applicable safety requirements for exposure to radio waves. The radio wave exposure guidelines employ a unit of measurement called Specific Absorption Rate (SAR). The recommended SAR limit for mobile handset is 1.6 W/Kg averaged over a 6 minutes period and taken over a volume containing a mass 1g of human tissue.

The highest SAR value for this mobile phone model is 0.168 W/kg averaged over a 6 minutes period and taken over a volume containing a mass 1g of human tissue.

Use cell phone when the signal strength is good. Keep your calls short or instead use headset or send a text message. This advice applies especially to children, adolescents and pregnant women.

If using Bluetooth headset device, please make sure it has a low power emitter.

Do not switch on your phone where phone use is prohibited or when phone use may cause interference or danger.
Do not use your phone while driving.
Follow the rules or regulations in hospitals and health care facilities. Switch off your phone near medical equipments.
Switch off your phone in an aircraft. The phone may cause interference to control signals of the aircraft.
Switch off your phone near high-precision electronic devices. The phone may affect the performance of these devices.
Do not attempt to disassemble your phone or its accessories. Only qualified personnel are allowed to service or repair the phone.
Do not place your phone or its accessories in containers with strong electromagnetic field.
Do not place magnetic storage media near your phone. Radiation from the phone may delete the information stored on them.
Do not put your phone in a high-temperature place or use it in a place with flammable gas such as a gas station.
Keep your phone and its accessories away from children. Do not allow children to use your phone without guidance.
Use approved batteries and chargers only to avoid explosion.

7 Frequently Asked Questions and Troubleshooting

If your phone appears the questions frequently please refer to the answers as follows. After that you cannot solve the questions please contact with the mobile phone dealers.

Questions	Check Proceeding
Not charging	Please check whether the correct link to the phone charger and power outlet.
Not Power-on	Please check the adequacy of electricity. Please check whether the correct installation of battery. Please long press the End Key by a sufficient length of time.
Not reading the information in the inserted card that inserted	Please check whether the correct R-UIM inserted. Please check your R-UIM effective. Please check the surface of your R-UIM clean.
Prompt to input PUK	Please contact with the service providers to obtain PUK code. Using the PUK to unlock.
Cannot dial a number	Please check whether the correct number. Please check whether the phone is in the function of forbidding all call. Please check whether you are in the service area.
Poor quality of the conversation	Please check whether the signal is strong. If you are in a building please turn the phone or move closer to the windows.
In the conversation, the other side did not hear your voice	Please check whether the microphone was standard or blocked something.
The voice of the telephone receiver is too small	Please check whether the volume of the telephone receiver adjust largest.

Bad signal reception or regular dropping	Please check whether there is a strong signal. Without signals please move to the strong signal area.
Out of the service area or network failure	Please check the area and try again after moved. Please check whether you did not apply the services options from the service provider. Please know the details from the service dealers.

Frequently Asked Questions	Cause and Solution
Fail to turn on	Press the power on key for over 1 second. Check if the battery is properly connected. Please remove and install it again, retry to turn on. Check if battery is appropriately charged
Fail to connect network	Weak signal. Please try and move to a location with strong signal and try connecting to the network again, Please ensure that you are not beyond the network coverage of service providers. Please ensure you have a valid SIM card. Please contact your network provider for further information.
Display information while turning on	Check if the SIM card (insert the SIM card) is installed correctly Handset lock password. If the handset lock is activated you have to input handset password before using.

	Input PIN. Inputting PIN while turning on each time is activated, you have to input the PIN code. Input PUK code: Having input wrong PIN code for 3 times straight will lock the SIM card. You need to input the PUK code provided by your network provider.
Poor quality of calling	Please check if the sound volume is tuned improperly. In an area with poor receiving condition for example: basement, the signal might be weak. Try reaching a location with stronger signal reception and call again. While using the mobile phone in the peak period of communication like commute time, you may be unable to call because of line congestion.
Standby duration shortened	The standby duration is relative to the system setting of network. While the mobile phone is in an area with poor signal strength and can not receive the signal, the handset will continuously search for a base station. This will significantly reduce battery charge. It is recommended that you turn off your mobile in area with no signal reception to save battery. Need replacing the battery. Please change a new battery.
SIM Card Error	Dirt on the metal surface of an SIM card. Use clean cloth to wipe the metal touch point on an SIM card. The SIM card is not installed. The SIM card is damaged. Please contact your network service provider.
Fail to dial out	Please confirm if you press the dial key after dialing. Please confirm if calling is forbidden because of defaulting. Please confirm if the SIM is valid.

	Please confirm if the call barring is set. Please confirm if the fixed dial function is set.
Callers cannot contact you	Please confirm if the mobile phone is on and connected with the network. Please confirm if calling is forbidden because of defaulting. Please confirm if the SIM card is valid. Please confirm if the call barring is set.
Fail to charge	Please check if the plug is connected well. Charge in the environment below 40℃ or above 55℃. Please change your charging port. The battery or charger is damaged. You need to replace it.
Fail to set some functions	Wrong operation. The network provider does not support the function or you have not applied for it.

Note: If the instruction above can not help you solve problems, please record：

Mobile phone model and serial number

Specific content of warranty

Clear statement of problems

Then contact your local dealer or a Karbonn authorized service center in your area.